

MODELS BGU • BGU-D

BARRIER GATE OPERATOR OWNER'S INFORMATION



IMPORTANT SAFETY INFORMATION AND WARNINGS



The enclosed blue Safety Precaution literature which accompanies this information is required reading for all users of this system. It is also necessary to read the directives in this packet to familiarize yourself with the proper operation of this equipment. If the information appears incomplete, contact your installing dealer or the manufacturer for a complete packet or explanation before operating this equipment. (OSCO toll-free number 1-800-333-1717)

- This automatic gate is for car and truck vehicular traffic only.
- Children must never be allowed to play on, near or around a motorized gate.
- Keep all control devices out of the reach of children.
- **Never operate this system without being in sight of the full path of travel of the moving gate!**
- Stand clear of the gate's path of travel at all times. Gate may start without audible warnings. Consult your installing dealer regarding audible/visual pre-start options.
- Replace broken arm with 1x4" (25x102 mm) soft wood only. Replacement arms and labels may be obtained from your OSCO distributor or dealer.
- There are no user-serviceable parts inside.
- Do not attempt to make repairs or adjustments to the operator. Call your dealer or a qualified service technician to perform repairs.
- The operator should be tested monthly by a qualified service technician.